
## **5 Tier Commodity Shelf**


## **ASSEMBLY INSTRUCTIONS**

The only tool you require is a MALLET



## **ASSEMBLY INSTRUCTIONS**

Attach a Plastic Foot to 1 end of 4 of the Keyhole Uprights. NOTE: Ensure keyholes are the correct way up. (Pic 1)




5 Steel connectors must be this way up



WARNING

2 Fit 2 Short Shelf Supports and 2 Long Shelf Supports to the bottom holes (for maximum strength) of 4 Keyhole Uprights by slotting the Keyhole Pins in the Supports into the Keyholes in the Uprights and tapping firmly with a hammer to seat in place. (Pic 2).



- (GO TO 4 IF YOU ARE NOT ASSEMBLING AS A WORKBENCH)
  - a) Fit 2 Short Shelf Supports and 2 Long Shelf Supports for the top of the Workbench into the holes at the top of the Keyhole Uprights.
  - b) Assemble the remaining Keyhole Uprights and Long and Short Shelf Supports to maker either a Straight Workbench or a Corner Workbench, using the same method as above.
  - c) Install MDF Shelves.
  - d) Bolt the 2 halves of the Workbench together if needed. (nuts and bolts not supplied).





Fit Long and Short Shelf Supports where you want the 2nd Shelf to be positioned. These Supports <u>must not</u> be in the top 2 holes of the Keyhole Upright. (Pic 3) (We have shelf position recommendations listed below).



To make 1 side of the top half of the Storage Unit: Fit 2 Short Shelf Support to 2 Keyhole Upright. Fit the top Support first. It must be located in the top 2 holes of the Upright. Then fit the 3rd Support in your chosen position. (Pic 5) Repeat this procedure to make



Place the 5 boards onto the 5 shelf change to supports and fit the remaining 4 plastic feet to the tops of the uprights



